LAGOON 52 F

Costabella_DB (2018)



BeBlue S.R.L. • Via Barche 53 • 30035 Mirano (Ve) • Italy

Telephone: +39 041 86 27 010

E-mail: info@beblue.it

Web: www.bebluesailing.com



PREMIUM EQUIPMENT: Air condition, Electric toilet, Electric winch, Heating, Watermaker - desalinator

DECK EQUIPMENTS: Anchor with chain, Bathing platform,
Bimini top, Black Water Tank, Cockpit cushions, Cockpit table,
Cockpit/stern, outside shower, Electric anchor windlass, Rail
openings both sides, Spring cleats, Swimming ladder, Teak
cockpit, 220 volt socket, Air condition, Battery charger, DSC
station, Inverter, Service batteries, Shore connection 220 V,
VHF radio, Water heater, Watermaker - desalinator, Electric
toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer,
Kitchen utensils (Galley equipment, cutlery), Microwave, Moka
pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass,
GPS chart plotter, GPS chart plotter - cockpit, Log/speed
instrument, Tridata, Wind instrument/Anemometer, CD player,
Indoor speakers, Outside speakers, Radio CD player, Stand up
paddle (SUP) - free, Wi-Fi Internet, Electric winch

ELECTRICAL SYSTEM: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger, DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio, Water heater, Watermaker - desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter - cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP) - free, Wi-Fi Internet, Electric winch

INTERIOR DESIGN: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger, DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio, Water heater, Watermaker - desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter - cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP) - free, Wi-Fi Internet, Electric winch

KITCHEN: Anchor with chain, Bathing platform, Bimini top,
Black Water Tank, Cockpit cushions, Cockpit table,
Cockpit/stern, outside shower, Electric anchor windlass, Rail
openings both sides, Spring cleats, Swimming ladder, Teak
cockpit, 220 volt socket, Air condition, Battery charger, DSC
station, Inverter, Service batteries, Shore connection 220 V,
VHF radio, Water heater, Watermaker - desalinator, Electric
toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer,
Kitchen utensils (Galley equipment, cutlery), Microwave, Moka
pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass,
GPS chart plotter, GPS chart plotter - cockpit, Log/speed
instrument, Tridata, Wind instrument/Anemometer, CD player,
Indoor speakers, Outside speakers, Radio CD player, Stand up
paddle (SUP) - free, Wi-Fi Internet, Electric winch

NAVIGATION SYSTEM: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger, DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio, Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP) – free, Wi-Fi Internet, Electric winch

PLEASURE EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger, DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio, Water heater, Watermaker - desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter - cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP) - free, Wi-Fi Internet, Electric winch

SAILING EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger, DSC