LAGOON 42

XIT (2019)



BeBlue S.R.L. • Via Barche 53 • 30035 Mirano (Ve) • Italy

Telefon: +39 041 86 27 010 E-mail: info@beblue.it

Web: www.bebluesailing.com







Port Wyjścia	Athens, Agios Kosmas Marina, Grecja
Jacht ID	32017
Sztocznia	Lagoon-Bénéteau
Boat Name	XIT
Rok	2019
Długość	12.80 M
Kabiny	4+2
Łóżka	8+2+2
Toaleta/ Prysznic	4

PREMIUM EQUIPMENT: Electric winch

DECK EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

ELECTRICAL SYSTEM: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

INTERIOR DESIGN: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

KITCHEN: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

NAVIGATION SYSTEM: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

PLEASURE EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

SAILING EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Battery charger, DSC station, Plug 220V, 12 V, Service batteries, Shore connection 220 V, Start battery, VHF radio, Water heater, Towels, Kitchen utensils (Galley equipment, cutlery), Moka pot, Refrigerator, Autopilot, Compass, GPS chart plotter, Tridata, Wind instrument/Anemometer, Indoor speakers, Outside speakers, Radio CD player, Wi-Fi Internet, Electric winch, Winch

OTHER EQUIPMENT: Dinghy with outboard engine