

SUN ODYSSEY 42I

MOITESSIER (2010)



BeBlue S.R.L. • Via Barche 53 • 30035 Mirano (Ve) • Italy

Telefon: +39 041 86 27 010

E-mail: info@beblue.it

Web: www.bebluesailing.com



Port Wyjścia	La Spezia, Włochy
Jacht ID	324995
Sztocznia	Jeanneau
Boat Name	MOITESSIER
Rok	2010
Długość	12.85 M
Kabiny	3
Łóżka	6 + 2
Toaleta/ Prysznic	2

PREMIUM EQUIPMENT: Heating

DECK EQUIPMENTS: Bimini top, Swimming ladder, Converter 220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot water, Kitchen utensils (Galley equipment, cutlery), Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart plotter, Log, Wind instrument/Anemometer, Radio CD mp3 player, Lifelines, Full batten main sail with eletric winsch and Lazy Bag, Furling jib, Lazy jacks

ELECTRICAL SYSTEM: Bimini top, Swimming ladder, Converter 220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot water, Kitchen utensils (Galley equipment, cutlery), Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart plotter, Log, Wind instrument/Anemometer, Radio CD mp3 player, Lifelines, Full batten main sail with eletric winsch and Lazy Bag, Furling jib, Lazy jacks

INTERIOR DESIGN: Bimini top, Swimming ladder, Converter 220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot water, Kitchen utensils (Galley equipment, cutlery), Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart plotter, Log, Wind instrument/Anemometer, Radio CD mp3 player, Lifelines, Full batten main sail with eletric winsch and Lazy Bag, Furling jib, Lazy jacks

KITCHEN: Bimini top, Swimming ladder, Converter 220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot water, Kitchen utensils (Galley equipment, cutlery), Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart plotter, Log, Wind instrument/Anemometer, Radio CD mp3 player, Lifelines, Full batten main sail with eletric winsch and Lazy Bag, Furling jib, Lazy jacks

NAVIGATION SYSTEM: Bimini top, Swimming ladder, Converter 220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot water, Kitchen utensils (Galley equipment, cutlery), Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart plotter, Log, Wind instrument/Anemometer, Radio CD mp3 player, Lifelines, Full batten main sail with eletric winsch and Lazy Bag, Furling jib, Lazy jacks

PLEASURE EQUIPMENTS: Bimini top, Swimming ladder, Converter 220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot water, Kitchen utensils (Galley equipment, cutlery), Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart plotter, Log, Wind instrument/Anemometer, Radio CD mp3 player, Lifelines, Full batten main sail with eletric winsch and Lazy Bag, Furling jib, Lazy jacks

SAFETY: Bimini top, Swimming ladder, Converter 220V/12V,
Plug 220V, 12 V, Szybka ładowarka, VHF radio , Heating, Hot
water, Kitchen utensils (Galley equipment, cutlery),
Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart
plotter, Log, Wind instrument/Anemometer, Radio CD mp3
player, Lifelines, Full batten main sail with eletric winsch and
Lazy Bag, Furling jib, Lazy jacks

SAILING EQUIPMENTS: Bimini top, Swimming ladder, Converter
220V/12V, Plug 220V, 12 V, Szybka ładowarka, VHF radio ,
Heating, Hot water, Kitchen utensils (Galley equipment, cutlery),
Refrigerator, Autopilot, Echosounder/Depthsounder, GPS chart
plotter, Log, Wind instrument/Anemometer, Radio CD mp3
player, Lifelines, Full batten main sail with eletric winsch and
Lazy Bag, Furling jib, Lazy jacks