

LAGOON 52 F

Costabella_DB (2018)




BeBlue S.R.L. • Via Barche 53 • 30035 Mirano (Ve) • Italy

Telefon: +39 041 86 27 010

E-mail: info@beblue.it

Web: www.bebluesailing.com



Port Wyjścia	Seychelles, Eden Island Marina, Seszele
Jacht ID	325987
Sztocznia	Lagoon-Bénéteau
Boat Name	Costabella_DB
Rok	2018
Długość	15.84 M
Kabiny	5 + 2
Łóżka	10 + 2
Toaleta/ Prysznic	5

PREMIUM EQUIPMENT: Air condition, Electric toilet, Electric winch, Heating, Watermaker – desalinator

DECK EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio , Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP)- FREE, Wi-Fi Internet, Electric winch

ELECTRICAL SYSTEM: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio , Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP)- FREE, Wi-Fi Internet, Electric winch

INTERIOR DESIGN: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio , Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP)- FREE, Wi-Fi Internet, Electric winch

KITCHEN: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio , Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP)- FREE, Wi-Fi Internet, Electric winch

NAVIGATION SYSTEM: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio , Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP)- FREE, Wi-Fi Internet, Electric winch

PLEASURE EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC station, Inverter, Service batteries, Shore connection 220 V, VHF radio , Water heater, Watermaker – desalinator, Electric toilet, Heating, Towels, Dishwasher, Electrical kettle, Freezer, Kitchen utensils (Galley equipment, cutlery), Microwave, Moka pot, Oven, Refrigerator, Stove, Toaster, Autopilot, Compass, GPS chart plotter, GPS chart plotter – cockpit, Log/speed instrument, Tridata, Wind instrument/Anemometer, CD player, Indoor speakers, Outside speakers, Radio CD player, Stand up paddle (SUP)- FREE, Wi-Fi Internet, Electric winch

SAILING EQUIPMENTS: Anchor with chain, Bathing platform, Bimini top, Black Water Tank, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Rail openings both sides, Spring cleats, Swimming ladder, Teak cockpit, 220 volt socket, Air condition, Battery charger , DSC