OCEANIS 41.1


JINTY BINTY ** (2019)



BeBlue S.R.L. • Via Barche 53 • 30035 Mirano (Ve) • Italy

Telefon: +39 041 86 27 010 E-mail: info@beblue.it

Web: www.bebluesailing.com



DECK EQUIPMENTS: Bimini top, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Sprayhood, Swimming ladder, 110V socket, Battery charger, Inverter, VHF radio, Convertible table, Electric fans in cabins, Kitchen utensils (Galley equipment, cutlery), Oven, Refrigerator, Stove, Autopilot, GPS chart plotter, Speedometer (Speed log), Wind instrument/Anemometer, Outside speakers, Lazy bag, Lazy jacks, Self tailing winch

ELECTRICAL SYSTEM: Bimini top, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Sprayhood, Swimming ladder, 110V socket, Battery charger, Inverter, VHF radio, Convertible table, Electric fans in cabins, Kitchen utensils (Galley equipment, cutlery), Oven, Refrigerator, Stove, Autopilot, GPS chart plotter, Speedometer (Speed log), Wind instrument/Anemometer, Outside speakers, Lazy bag, Lazy jacks, Self tailing winch

INTERIOR DESIGN: Bimini top, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Sprayhood, Swimming ladder, 110V socket, Battery charger, Inverter, VHF radio, Convertible table, Electric fans in cabins, Kitchen utensils (Galley equipment, cutlery), Oven, Refrigerator, Stove, Autopilot, GPS chart plotter, Speedometer (Speed log), Wind instrument/Anemometer, Outside speakers, Lazy bag, Lazy jacks, Self tailing winch

KITCHEN: Bimini top, Cockpit cushions, Cockpit table,
Cockpit/stern, outside shower, Electric anchor windlass,
Sprayhood, Swimming ladder, 110V socket, Battery charger,
Inverter, VHF radio, Convertible table, Electric fans in cabins,
Kitchen utensils (Galley equipment, cutlery), Oven, Refrigerator,
Stove, Autopilot, GPS chart plotter, Speedometer (Speed log),
Wind instrument/Anemometer, Outside speakers, Lazy bag,
Lazy jacks, Self tailing winch

NAVIGATION SYSTEM: Bimini top, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Sprayhood, Swimming ladder, 110V socket, Battery charger, Inverter, VHF radio, Convertible table, Electric fans in cabins, Kitchen utensils (Galley equipment, cutlery), Oven, Refrigerator, Stove, Autopilot, GPS chart plotter, Speedometer (Speed log), Wind instrument/Anemometer, Outside speakers, Lazy bag, Lazy jacks, Self tailing winch

PLEASURE EQUIPMENTS: Bimini top, Cockpit cushions,
Cockpit table, Cockpit/stern, outside shower, Electric anchor
windlass, Sprayhood, Swimming ladder, 110V socket, Battery
charger, Inverter, VHF radio, Convertible table, Electric fans in
cabins, Kitchen utensils (Galley equipment, cutlery), Oven,
Refrigerator, Stove, Autopilot, GPS chart plotter, Speedometer
(Speed log), Wind instrument/Anemometer, Outside speakers,
Lazy bag, Lazy jacks, Self tailing winch

SAILING EQUIPMENTS: Bimini top, Cockpit cushions, Cockpit table, Cockpit/stern, outside shower, Electric anchor windlass, Sprayhood, Swimming ladder, 110V socket, Battery charger, Inverter, VHF radio, Convertible table, Electric fans in cabins, Kitchen utensils (Galley equipment, cutlery), Oven, Refrigerator, Stove, Autopilot, GPS chart plotter, Speedometer (Speed log), Wind instrument/Anemometer, Outside speakers, Lazy bag, Lazy jacks, Self tailing winch

OTHER EQUIPMENT: Convertible table in salon, Depthsounder, Dinghy, Fusion radio, Outboard engine, USB socket